

## Monitor Hook Up Versa-Pak (with starter)

These instructions are for the hooking up a monitor to a power unit with Versa-Pak control system and a starter. For Motor Drive installation see appropriate instructions. DO NOT use these instructions for power units with motor drives (i.e. VFD's, Vector Drives, etc.)!

If you have any questions, please call us at 352-742-4774.

### ONEPLUS:

(H) Black wire goes on Versa-Pak terminal block #2.

(G) Ground wire goes on Versa-Pak green (ground) terminal block.

(N) White wire goes on Versa-Pak terminal block #1.

### Waste Management Monitor:

(HOT) Black wire goes on Versa-Pak terminal block #2.

(NEUT) White wire goes on Versa-Pak terminal block #1.

(GRD) Green wire goes on Versa-Pak green (Ground) terminal.

(MOTOR) Violet wire goes on Versa-Pak terminal block #5.

### SmartTrash Monitor

Green wire goes on green/yellow Versa-Pak terminal block (ground)

Black wire goes on Versa-Pak terminal block #2

Red wire goes on Versa-Pak terminal block #7

Brown wire goes on Versa-Pak terminal block #3

Yellow - if you are not using key switch option you can wire to #2A and wire the haul switch to Versa-Pak terminal blocks 2 and 2A. Otherwise it may be best to wire yellow monitor wire to haul switch with wire nut and other side of haul switch to #2.