Keypad Start Reset Programming Support: www.versa-pak.net 352-742-4774

<u>Issue:</u> No codes work. 31130* gives 5 beeps.

Reset Programming

Disconnect power to compactor. Remove face to keypad. Move the DAP jumper from the OFF to the ON position (top right hand corner of board) Reconnect the power supply to the compactor. Keypad will start beeping. Move the DAP jumper back to the OFF position. Keypad will stop beeping and the yellow LED will be on solid. The keypad is now in programming mode. Enter 031130# The keypad will beep twice indicating the installer code is accepted. Enter * to exit program mode.

Enter 31130* Keypad will beep twice Enter 1001357# Keypad will beep twice Enter *

Adding another user code if needed. Otherwise proceed to next section:

Enter 31130* Keypad will beep twice Enter 101 [4 to 8 digit code you would like to use] # Keypad will beep twice Enter *

Keypad Start- You are done! Enter 1357# to start compactor.

Keypad Off/On ONLY-

Etner 31130* Keypad will beep twice Enter 40300# Enter *

Keypad Door Strike ONLY-

Enter 31130* Keypad will beep twice Enter 4060# Enter *